



## FOR LAMINATE DIY INSTALLATIONS YOU WILL NEED THE FOLLOWING:

- Utility Knife
- Carpenters Square
- Tape Measure
- Spacers and Tapping Block
- Level
- Hammer
- Vapor Barrier
- Circular and Normal Saw
- Pencil

NB: The floor must be level, not exceeding a variation dip of 3mm anywhere which will then require a [self-levelling screed to be applied](#)

[HOME](#) | [MORE DIY PRODUCTS](#) | [INSTALLATION VIDEO](#) | [FIND A BRANCH](#)