

# CARING FOR YOUR LAMINATE FLOORING.



With its smooth surface structure, Laminates cannot absorb dirt or dust, but remove dust, sand, and grit particles by sweeping or vacuuming regularly with the suction segment only. Don't use a vacuum with a beater as it may scratch your floor or dull the floor finish.



To keep your floors clean and in a pristine condition, use FloorGuard Laminate, SPC and LVT Cleaner approximately once a week or bi-monthly. Spray a mild solution of FloorGuard onto a fibre mop pad. Gently wipe the boards and allow to dry. Do not over wet to prevent excess moisture penetrating between the joints.



Use a clean cloth or paper towel to blot up spills as soon as they happen.



Never use scouring products



Use ice to harden tough substances like wax or chewing gum, and then gently scrape with a plastic scraper or a credit card being careful not to scratch the surface. Wipe the area clean with a soft, slightly damp cloth.



Keep your pets nails trimmed to prevent them from scratching your floor.



Never try to slide heavy objects across the floor or place the objects where they might prevent the flooring from expansion & contraction.



Before placing any chairs or furniture on your new Laminate floors always check the condition of the feet, and affix felt pads so as to prevent any potential cuts or scratches. Use a protective mat for furniture or chairs with castors.



Avoid excessive exposure to water.



Entry mats will help collect the dirt, sand, grit and other substances such as oil, asphalt or driveway sealer that might otherwise be tracked onto your floor. Placing mats in high-traffic areas - in front of vanities, kitchen sinks, and stoves - is an effective way to reduce wear. Never use mats with a rubber backing.



Never apply layers of wax or varnish to Laminates.



Use protective window coverings to block fade-causing UV rays and excessive heat from direct sunlight, and rearrange rugs and furniture periodically to help your floor age evenly.